

Cornice Designs

from

drapesmadeeasy.com

Terms of use

This document is for your personal use only, or for the use of the company you represent (you may use it for as many clients as you wish).

The contents of this document are protected by copyright under international conventions. The reproduction or retransmission of the contents of this document is prohibited.

You agree to use the contents of this document entirely at your own risk.

Please respect the work we at drapesmadeeasy.com put into producing this document by only using it under the conditions stated above.

Demo

This demo version has two designs so you can check you are able to print them out on your printer.

You can [buy the full version here](#).

Introduction

The pages in this pdf document contain patterns for upholstered cornice designs. Sizes are given in inches and centimetres. One half of each design is printed off because they are symmetrical. If the center section is straight then just the necessary part of the left hand side is printed.

The designs are divided into two sections. One section is in US Letter size for printing on US Letter paper. The other is in A4 size for printing on A4 paper.

Instructions

1. From the tables on the following pages find the design you would like to print.
2. From that row find the closest size of design to the size you want if there is a choice.
3. Make a note of the pages you need to print. **Make sure to select the page numbers under the page size your printer is using, either US Letter or A4.**
4. Select "File" and "Print" from the program you're using to view this document.
5. Your printer options should include 'Print All Pages' and 'Print Selected Pages'. (Print Selected Pages is often in the form "From" and "To".) **You need to print only the page numbers you found in step 3.** Make sure you input only the relevant page numbers, for example, From page 56 To page 64.

Do not leave the setting on 'Print All'! If you do, you will print out all the pages, and there are over 670 of them!

6. Some printers may change the Scale setting, and try to print at a percentage such as 97%. If you can, change this to 100% so the design prints at the full size.
7. Print the pages.
8. Cut each page wherever there is a dashed line.
9. Lay page 2 on 1, aligning the cut edge of page 2 with the vertical marks on page 1. The page overlaps by about 0.25 inches. Stick page 2 to page 1 with adhesive or tape. If there are more pages repeat in the order given.
10. Cut out the design. You can now fix this over your window to check how it looks and use it as a template to transfer the design to hardboard or buckram.


Notes


Maximum depth: the depth of the deepest section of the design.

Width: if applicable, the total width of the design. Some designs are supplied in 5 foot and 8 foot widths (153 and 244 cms). Other designs which have a straight center section can be any width.

Only the left hand section is printed, as all designs are symmetrical.

There is more information on straight cornices and adapting the supplied designs on the pages after the design tables.

Cornice shape	Max. depth	Width	Pages to print	
			US Letter	A4
	17 inches (43 cms)	Any	9 - 12	29 - 32
	17 inches (43 cms)	Any	13 - 16	340 - 343
	19 inches (48 cms)	Any	17 - 20	344 - 347
	19 inches (48 cms)	Any	21 - 24	348 - 351
	19 inches (48 cms)	Any	25 - 28	352 - 355
	18 inches (46 cms)	5 feet (153 cms)	29 - 34	356 - 361
		8 feet (244 cms)	35 - 44	362 - 370
	18 inches (46 cms)	5 feet (153 cms)	45 - 50	371 - 376
		8 feet (244 cms)	51 - 62	377 - 385
	14 inches (36 cms)	Any	63 - 68	386 - 391
	20 inches (51 cms)	5 feet (153 cms)	69 - 75	392 - 398
		8 feet (244 cms)	76 - 86	399 - 410
	18 inches (46 cms)	5 feet (153 cms)	87 - 94	411 - 418
		8 feet (244 cms)	95 - 106	419 - 431
	20 inches (51 cms)	5 feet (153 cms)	107 - 113	432 - 438
	22 inches (56 cms)	8 feet (244 cms)	114 - 123	439 - 449
	13 inches (33 cms)	5 feet (153 cms)	124 - 131	450 - 457
	15 inches (38 cms)	8 feet (244 cms)	132 - 143	458 - 471

Cornice shape	Max. depth	Width	Pages to print	
			US Letter	A4
	14 inches (36 cms)	5 feet (153 cms)	144 - 151	472 - 479
	17 inches (43 cms)	8 feet (244 cms)	152 - 163	480 - 493
	10.5 inches (27 cms)	5 feet (153 cms)	13 - 16	33 - 36
	12 inches (30 cms)	8 feet (244 cms)	17 - 28	37 - 46
	16 inches (41 cms)	5 feet (153 cms)	180 - 185	508 - 513
	18 inches (46 cms)	8 feet (244 cms)	186 - 194	514 - 523
	17 inches (43 cms)	5 feet (153 cms)	195 - 202	524 - 529
	18 inches (46 cms)	8 feet (244 cms)	203 - 214	530 - 543
	16 inches (41 cms)	5 feet (153 cms)	215 - 220	544 - 549
	18 inches (46 cms)	8 feet (244 cms)	221 - 230	550 - 560
	18 inches (46 cms)	5 feet (153 cms)	231 - 237	561 - 567
	19 inches (48 cms)	8 feet (244 cms)	238 - 247	568 - 578
	17 inches (43 cms)	5 feet (153 cms)	248 - 255	579 - 586
	19 inches (48 cms)	8 feet (244 cms)	256 - 267	587 - 600
	7 inches (18 cms)	Any	268 - 269	601 - 602
	10 inches (25cms)	Any	270 - 273	603 - 606
	7 inches (18 cms)	Any	274 - 276	607 - 609
	10 inches (25cms)	Any	277 - 280	610 - 614
	22 inches (56 cms)	5 feet (153 cms)	281 - 288	615 - 622
	22 inches (56 cms)	5 feet (153 cms)	289 - 296	623 - 630
	22 inches (56 cms)	5 feet (153 cms)	297 - 304	631 - 638

Cornice shape	Max. depth	Width	Pages to print	
			US Letter	A4
	22 inches (56 cms)	5 feet (153 cms)	305 - 312	639 - 646
	22 inches (56 cms)	5 feet (153 cms)	313 - 320	647 - 654
	22 inches (56 cms)	5 feet (153 cms)	321 - 328	655 - 662
	17 inches (43 cms)	Any	329 - 335	663 - 670

In the full version this page has information on cornice designs and adapting them for your window sizes.

Demo

In the full version this page has information on additional features you can use to improve your cornice designs.

Demo

Making a cornice

There are many methods for making an upholstered cornice. You can find out more about the methods we recommend on the [main cornice page](#) on the website. There are also more details on the advantages of using cornices.

Here's the page on making a cornice [using buckram](#) to stiffen it, or my preferred method [using hardboard](#).

The way most professionals fit their cornices is by attaching it to a [mounting board](#). This gives a very secure fixing.



Top Left Corner

Cut along the dashed lines
Pages will overlap by 0.25 inches



Arrange in this order:




© 2013 www.drapesmadeeasy.com




© 2013 www.drapesmadeeasy.com



© 2013 www.drapesmadeeasy.com



4





Top Left Corner

Cut along the dashed lines
Pages will overlap by 0.25 inches




© 2013 www.drapesmadeeasy.com


Arrange in this order:




© 2013 www.drapesmadeeasy.com



© 2013 www.drapesmadeeasy.com



© 2013 www.drapesmadeeasy.com





Top Left Corner

Cut along the dashed lines
Pages will overlap by 0.25 inches



© 2013 www.drapesmadeeasy.com


Arrange in this order:

1	2	3	4	5	6
7	8	9	10	11	12




© 2013 www.drapesmadeeasy.com


© 2013 www.drapesmadeeasy.com



9










Cut along the dashed lines
Pages will overlap by 1.0 cm



Top Left Corner

© 2013 www.drapesmadeeasy.com


Arrange in this order:




© 2013 www.drapesmadeeasy.com



© 2013 www.drapesmadeeasy.com



4






Cut along the dashed lines
Pages will overlap by 1.0 cm




Top Left Corner


© 2013 www.drapesmadeeasy.com


Arrange in this order:





© 2013 www.drapesmadeeasy.com







Top Left Corner

Cut along the dashed lines
Pages will overlap by 1.0 cm



© 2013 www.drapesmadeeasy.com

Arrange in this order:


1	2	3	4	5
6	7	8	9	10



© 2013 www.drapesmadeeasy.com

© 2013 www.drapesmadeeasy.com


© 2013 www.drapesmadeeasy.com



7

© 2013 www.drapesmadeeasy.com

© 2013 www.drapesmadeeasy.com



© 2013 www.drapesmadeeasy.com



10

